Kids Don't Fly

Prevent falls from windows and balconies

Window Safety Product Guide

Stop windows from opening more than 12.5cm Window Type **Window Safety Emergency Escape Product Type** Single Sliding Casement Awning and Double-Hopper Hung Mounting Guard Release Yes 🗸 Yes 🗸 Yes 🗸 Yes 🗸 Window Guard mounts buttons are fixed allow for quick to window frames removal of guard in an with screws. emergency. **Window Restrictor** Unlock with Yes 🗸 Yes 🗸 Yes 🗸 Yes 🗸 Device is attached key and disengage to window window frames with restrictor screws. to open window.

Window Safety Product Type			Single and Double- Hung	Sliding	Casement	Awning or Hopper
Safety Nets	Anchorage is fixed to the whole window frame with screws, with nets hooked on to anchorage.	Adults can remove netting from anchorage system.	Yes 🗸	Yes 🗸	No X	No 🗶
Key operated window locks Various types available from hardware stores and lock suppliers	Device is attached to window frame with screws. Can be mounted to limit window opening to 12.5cm.	Device is unlocked via a key.	Yes 🗸	Yes 🗸	No x	No x

Check that any window safety product you purchase has been subjected to load testing. This ensures that the device is able to stop a child who falls against the window, from falling out. As there is no Australian Standard for Window Fall Prevention Devices, Australian products are tested against a variety of international standards with a minimum load testing of 333N as required by the American Standard Specification for Window Fall Prevention Devices.



For information and translations, visit www.health.nsw.gov.au/childsafety

